

R-1201

BMW (E36) '95 -'99 - HARNESS MOUNT
INSTALLATION INSTRUCTIONS

Note: This mount bar has been designed to provide a mounting point for the shoulder straps of a 5 or 6 point off road harness system. Note: loctite on all threads is recommended.

Steps (1 - 7) are for installing the rear mounting brackets. These brackets remain in the vehicle so these steps are done just once.

Step 1

Remove rear lower seat cushion lift up at lower edge as shown.



Step 2

Remove outside seat back cushions. Carefully pull at top rear edge, rotate & pivot to clear lower pivot pin.



Step 3

Remove rear inside 1/4 panels carefully - pop out.




Step 4

Remove outside rear seat belt buckle, mounting bolt and washers.



Step 5

Position BK rear mounting bracket with factory buckle. Replace factory hardware with supplied bolts and washers. Make sure thread engagement is sufficient. The bolt should thread into the body at least one diameter of the bolt.



Step 6

Reinstall buckle/BK bracket assembly as shown.



Step 7

Position rear interior panel as shown. Notice that the BK rear mounting bracket is visible after installation.



Step 8

Reverse steps (1-2) to reassemble interior panel as shown below. **Tip:** Use a small phillips screw driver to reposition the rubber gasket over rear interior panel as shown below.



Steps (9 - 14) are the steps required to remove and reinstall the bar between uses.

**Step 9**

Carefully position main bar as shown and attach it to the rear mounting brackets using supplied bolts and washers. Finger tighten only.

**Step 10**

Carefully remove the plastic cover at lower shoulder strap mounting point located along the doorsill to expose the mounting bolt.

**Step 11**

Remove the mounting bolt, spacer and clip.

Step 12

Position support rod with (1) aluminum spacer (supplied) on each side of the rod. Install factory bolt as shown -(finger tighten)



Step 13

Raise main bar and attach support rods with supplied hardware as shown.

Note: The shoulder strap is located inboard of the seat support rod.



Step 14

Tighten all hardware. Recheck after use.



Finished install should look like this. Check function of the factory seat belt. It should function without interference from the bk harness mount. If there is interference, recheck the installation.



Note: Belts are to be wrap mounted around the main tube.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.