

R-2015

FIRE EXTINGUISHER BRACKET INSTALLATION INSTRUCTIONS

This fire extinguisher bracket is designed to mount a 2.5 lb fire extinguisher to the driver or passenger non-powered, Porsche factory seat.

Our mounting bracket adapts the bracket supplied with the extinguisher to the seat. The hole pattern on our bracket matches the hole pattern on the bracket supplied with *AMEREX* extinguishers. If your bracket does not match our hole pattern drill (4) 1/4" diameter holes in your bracket using the supplied template.

Step 1

Remove the seat from the vehicle. This is done by removing the seat bracket to floor mounting bolts (4 or 6 depending on model and year).

Step 2

Remove the seat tracks from the seat by removing the seat track to seat mounting bolts (4).

Step 3

Reinstall the seat tracks, sandwich the extinguisher mount between the tracks and the (2) front mounting points on the seat, and the (2) supplied shims at the (2) rear mounting points. (see assembly drawing)

Step 4

Reinstall the seat in the vehicle.

Step 5

Attach the mounting bracket supplied with the fire extinguisher to the Brey-Krause mount using the (4) #10-24 screws supplied.

Step 6

Install the fire extinguisher.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.

