

SH HKLRBB Installation Instructions



1) Secure helmet to prevent damage and ensure ease of installation



2) Remove the cheek pad of the side you wish to have the microphone placed on. The chin pad can also be removed to help with the installation if you wish.



3) Locate the word "TALK" on the Mic Boom. This is the side that will be facing the user. This orientation is important to get correct.



3.1) Place the mic into the cheek pad tray while keeping in mind the "TALK" orientation on the microphone. The edge of the last stem block should be in line with the edge of the chin strap outlet.



3.2) Place the included strip of nomex tape over top of the microphone boom to help hold it and place all the equipment into the helmet for step 6.



4) Find the connector tether and work the clip onto the rubber seal around the bottom. It is recommended to take your time and carefully use a small screwdriver to help guide the part over the seal.



4.1) Carefully work the clip into place as shown. It needs to be as far back against the main EPS as possible.



5) In the same manner as in step 4 and 4.1, carefully install the earbud clip on the same side as your microphone and move into place wherever is most comfortable for the driver.



10) Install a cheek pad, then the chin pad followed by the remaining cheek pad. Don't forget the chin straps!



11) Drop the earbud connector into the clip as shown and you're ready to go.