

SH HKRCD Installation Instructions



1) Secure helmet to prevent damage and ensure ease of installation



2) Remove both cheek pads as well as the chin pad from the helmet.



3) Remove the ear pads from the chin pads. They are secured with small pieces of velcro.



4) Located the earcup that says UP-R. This denotes that it is the Right earcup and should be installed into the right cheekpad with UP towards the top of the helmet.



5) Place the cheek pad and microphone loosely into the helmet and move to step 6.



6) Find the connector tether and work the clip onto the rubber seal around the bottom. It is recommended to take your time and carefully use a small screwdriver to help guide the part over the seal.



6.1) Carefully work the clip into place as shown. It needs to be as far back against the main EPS as possible.



7) In the same manner as in step 6 and 6.1, carefully install the earbud clip and move into place wherever is most comfortable for the driver.



8) Place the extra speaker cup and earbud wire outside of the shell then pull the chin strap through the cheek pad and secure. The chin pad can be installed back into the helmet anytime between steps 7 and 9.



8) Secure the speaker wire in around the back of the helmet by tucking it in with a blunt tool as shown.



9) Pull the chin strap through the cheek pad outlet and snap it back into place.



10) Install remaining earcup into the helmet.



11) Drop the earbud connector into the clip as shown and you're ready to go.