

Advantage PEET® Dryer - Model M07F

1. Attach the standard equipment Footwear DryPorts onto the PEET AirChamber tubes.
2. Plug fan unit into outlet.
3. Locate the switch that indicates the choice of using heated air or room temperature air. Move the switch to the desired setting.
4. Rotate dial to select desired length of time for drying. Maximum time is 180 minutes or three hours. Time is displayed on the LED readout and will count down until time expires, when the unit will automatically shut off.

PEET® Pure: This product uses ionization technology, which will remain functional whether the dryer is operating with or without heat. Ionization technology arrests bacteria growth and precipitates many airborne contaminants including pollen, dust and dust mites, viruses, animal dander, odors and toxic chemical fumes — most of which contain positive ions. Ionization technology produces negative ions, which are drawn to positive ions. The negative ions weigh down the contaminant particles, causing them to become too heavy to remain airborne. As a result, the contaminants will drop out of the air or, in this case, out of your footwear or gear.

IMPORTANT NOTES:KEEP AIR VENTS AT THE BACK OF THE BASE FREE OF OBSTRUCTION.

THERE MUST BE AT LEAST 6 INCHES OF CLEARANCE BETWEEN THE TOP OF THE FOOTWEAR AND THE BASE OF THE DRYER. This will allow the warm air to move freely for proper drying.

DO NOT PLACE FOOTWEAR OR GEAR DIRECTLY ONTO THE AIRCHAMBER TUBES, WITHOUT DRYPORT ATTACHMENTS. The patented PEET DryPorts are designed to circulate the warm air through footwear, minimizing drying time and maximizing effectiveness. Failing to use DryPort attachments blocks proper air circulation, limiting the dryer's ability to move air freely and may cause the product to overheat.

DO NOT PLACE THE PEET DRYER CLOSE TO A SECOND HEAT SOURCE, such as a furnace register.